

CUSTOMERS ARE **REQUIRED** TO CONTACT THE LOCAL POST OFFICE BEFORE INSTALLING THE MAILBOX TO ENSURE ITS CORRECT PLACEMENT AND HEIGHT AT THE STREET. GENERALLY, MAILBOXES ARE INSTALLED AT A HEIGHT OF 41-45 IN. FROM THE ROAD SURFACE TO INSIDE FLOOR OF THE MAILBOX OR POINT OF MAIL ENTRY (LOCKED DESIGNS) AND ARE SET BACK 6-8 IN. FROM FRONT FACE OF CURB OR ROAD EDGE TO THE MAILBOX DOOR.

SE **EXIGE** A LOS CLIENTES DIRIGIRSE A LA OFICINA DE CORREOS LOCAL ANTES DE INSTALAR EL BUZÓN PARA ASEGURAR SU COLOCACIÓN CORRECTA CON RESPECTO A LA ALTURA DE LA CALLE. GENERALMENTE, LOS BUZONES SE INSTALAN A UNA ALTURA DE 41 A 45 PULGADAS (104,1 cm - 114,3 cm) DE LA SUPERFICIE DEL CAMINO HASTA EL FONDO DEL BUZÓN O EL PUNTO DE ENTRADA DE LA CORRESPONDENCIA (DISEÑOS CON SEGURO) Y ESTÁN ALEJADOS 6 A 8 PULGADAS (15,2 A 20,3 cm) DE LA PARTE FRONTAL DE LA CALZADA O EL BORDE DEL CAMINO HASTA LA PUERTA DEL BUZÓN.

ADJUSTABLE LATCH INSTRUCTIONS INSTRUCCIONES AJUSTABLES DE PICAPORTE

Door catch tension can be adjusted by bending the hook up or down with pliers.
Ajustar tensión de puerta doblando gancho arriba o abajo con tenazas.

